

Creative SERVING CHILL ALL

Chill All Controller Programming

Models
CH1, CH2, CHN



To access the code protected parameters of the Chill All digital controller:

- Press and hold set until **PS (Password)** comes up. Press set and then the up arrow until 22 is displayed. Press set to confirm.
- Press the up arrow or down arrow until **/5 (Celsius/Fahrenheit)** comes up on the display. Press the up arrow until **1** comes up on the display. Press set to confirm this setting and return back to the other parameters.
- Press the up arrow or down arrow until **r3 (Operating Mode)** comes up on the display. Press the up arrow until **1** comes up on the display. Press set to confirm this setting and return back to the other parameters.
- Press the up arrow or down arrow until **rd (Control Differential)** comes up on the display. Press the up arrow until **2** comes up on the display. Press set to confirm this setting and return back to the other parameters.
- Press the up arrow or down arrow until **d1 (Interval Between Defrosts)** comes up on the display. Press the up arrow until **0** comes up on the display. Press set to confirm this setting and return back to the other parameters.
- Press the up arrow or down arrow until **/4 (Probe Input Displayed)** comes up on the display. Press the up arrow until **1** comes up on the display. Press set to confirm this setting and return back to the other parameters.
- Press the up arrow or down arrow until **do (Type Of Defrost)** comes up on the display. Press the up arrow until **2** comes up on the display. Press set to confirm this setting and return back to the other parameters.
- Press the up arrow or down arrow until **r1 (Minimum Set Point)** comes up on the display. Press the up arrow until **10** comes up on the display. Press set to confirm this setting and return back to the other parameters.
- Press the up arrow or down arrow until **r2 (Maximum Set Point)** comes up on the display. Press the up arrow until **50** comes up on the display. Press set to confirm this setting and return back to the other parameters.
- - Press the up arrow until **/C1 (Probe Differential)** comes up on the display. Press set then the up arrow until 20 comes up on the display. Press set to confirm this setting and return back to the other parameters.
- Press and hold set to confirm these parameter settings and to exit out of programming mode. The temperature reading will now be displayed

Creative Serving Inc.
5 Stahuber Avenue
Union, NJ 07083
Phone: 908-688-0800
Fax: 908-688-0718

CSP06275 REV 1